


Winding the bobbin



Instructions

1. Turn power switch to «on».
2. Place empty bobbin on winder.
3. Place thread spool and appropriate spool cap on pin.
4. Following the arrow guide, thread from the spool through thread guide **1** and around the pre-tension **2** stud to the winder.
5. Wind the thread around the bobbin a few times in the direction on the arrow.
6. Press the engaging lever **3** against the bobbin.
7. Press the foot control if necessary.
8. Winding stops when the bobbin is filled.
9. Remove bobbin.
10. Cut the thread using thread cutter **4**.