


BERNINA 530



- | | | |
|--|---|--|
| 1 Bobbin cover | 21 Balance button | 41 Feed dog |
| 2 Stitch plate | 22 Stitch width buttons | 42 Presser foot pressure adjustment wheel |
| 3 Attachment base for special accessories | 23 Needle position buttons | 43 Thread cutter on the headframe |
| 4 LED sewing light | 24 Stitch length buttons | 44 Slide-on table socket |
| 5 Quick reverse button | 25 Bobbin winder device | 45 Darning hoop connection |
| 6 Pattern endrepeat button | 26 Thread cutter on bobbin winder | |
| 7 Start/stop button | 27 Stitch selection buttons | |
| 8 Thread take-up cover | 28 BSR button | |
| 9 Thread take-up lever | 29 «clr» (clear) button | |
| 10 Bobbin winder pre-tension | 30 Free hand system connection | |
| 11 Navigation buttons | 31 Thread tension adjustment wheel | |
| 12 OK button | 32 Handwheel | |
| 13 Home button | 33 PC-Connection for software update | |
| 14 Back button | 34 Foot control socket | |
| 15 Display | 35 Feed dog drop | |
| 16 Speed control | 36 Power switch | |
| 17 Needle stop button down/up | 37 Power plug socket | |
| 18 Securing button | 38 Needle threader | |
| 19 Mirror image button | 39 Needle clamp | |
| 20 Pattern begin button | 40 Presser foot | |